Hot Plate Instructions

Set Up & Use

- Fully unwind the power cord before connecting to the power point
- Hot plate will draw approximately 7 amps of power. You'll require one full circuit in a domestic household
- The cooking utensil used should have a flat, solid bottom and be as even as possible
- Utensils with convex bottoms are unsuitable e.g. Woks
- The diameter of the bottom of the utensil must not be smaller than the hotplate nor should it be over 30mm larger than the hotplate

Trouble shooting

- Check power is turned on
- Check circuit breaker has not been tripped
- If Circuit breaker has been tripped reset and connect hotplate to another power supply or turn off the other appliances drawing power from the same source

Please note Place Settings takes all precautions to ensure that this unit is properly maintained and checked prior to delivery.

For further assistance please contact the Place Settings Duty Manager (03)9681 9191.

Innovative Hiring

Unit 7, 335 Ingles Street, Port Melbourne 3207 T: 03 9681 9191 F: 03 9681 9193
hire@placesettings.com.au www.placesettings.com.au ABN 41 071 861 599