Wok Burner Instructions

Setup & Use

- Ensure that the hoses and fitting are properly connected. Gas threads tighten anti clockwise
- Please note that the Wok Burner is supplied with a high-flow regulator. Do not use a different regulator on the Wok Burner. Do not use this regulator on another appliance.

Ignition

- To light the burner turn the control knob anti-clockwise until it clicks
- Repeat until lit
- Adjust flame to suit using the temperature control knob

Troubleshooting

- No gas: Check gas bottle is turned on and hose is securely connected
- Safety: Due to the high-flow regulator the Wok Burner has a high flame height - be careful when lighting it
  Do not place any articles/items next to/on top of wok burner
  Ensure there is adequate ventilation behind and above oven
  Minimum distance behind - 30cm, min distance above- 200cm
  Always turn the gas off at the bottle before turning wok burner off
- If You Smell Gas:
  i. Turn off gas supply at bottle and extinguish all flames.
  ii. Ventilate the area and check unit for leaks.
  iii. If odour persists, contact Place Settings Duty Manager.

Please note Place Settings takes all precautions to ensure that this unit is properly maintained and checked prior to delivery.

For further assistance please contact the Place Settings Duty Manager (03)9681 9191.

Innovative Hiring

Unit 7, 335 Ingles Street, Port Melbourne 3207 T: 03 9681 9191 F: 03 9681 9193
hire@placesettings.com.au www.placesettings.com.au ABN 41 071 861 599